

How to Prevent Hard Water Spots in a Polished Granite Shower

A good quality application of silicon impregnator should do the trick. It may also be helpful to install a water treatment system to reduce the calcium in the water.

TIP If you squeegee and/or dry the shower wall immediately after a shower you will find the water spots are easier to remove or possibly won't occur at all.

For more information, register to earn a [Stone Restoration Master Course Certificate](#). You'll learn how to restore natural stone floors, countertops, and walls, engineered stone, and granite floors, using the most efficient and effective restoration procedures. Also included in this program is the [Stain Care Pro](#) course with a one-year subscription to the Stain Care Pro app and [Understanding Sealers](#).

Online URL:

<https://sr-manual.com/kb/article/how-to-prevent-hard-water-spots-in-a-polished-granite-shower-711.html>