

Poultice Application Temperature

A poultice will work best at temperatures above 75 degrees Fahrenheit. Do not apply poultice below freezing temperatures.

CAUTION Do not attempt to heat a poultice. Certain chemicals will ignite or explode when heated. Refer to the MSDS.

Online URL:

<https://sr-manual.com/kb/article/poultice-application-temperature-673.html>