How to Prevent Hard Water Spots in a Polished Granite Shower

A good quality application of silicon impregnator should do the trick. It may also be helpful to install a water treatment system to reduce the calcium in the water.

TIP If you squeegee and/or dry the shower wall immediately after a shower you will find the water spots are easier to remove or possibly won't occur at all.

For more information, register to earn a Stone Restoration Master Course Certificate. You'll learn how to restore natural stone floors, countertops, and walls, engineered stone, and granite floors, using the most efficient and effective restoration procedures. Also included in this program is the Stain Care Pro course with a one-year subscription to the Stain Care Pro app and Understanding Sealers.

Online URL:
https://sr-manual.com/kb/article/how-to-prevent-hard-water-spots-in-a-polished-granite-shower-711.html